

DANCOVER[®]



**PARTY TENT SEMI PRO, CombiTent
7x12m - Side height 2,3m**

DANCOVER[®]



Safety Advice

Attention

In some countries approval is needed to set up a marquee/tent larger than 75 m². It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions.

In the event of snow, always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof, as heavy snow can cause the marquee/tent to collapse.

In the event of rain, there is a risk of rain puddles building up on top of the roof of the marquee/ tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero, always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.

Note: Marquees are intended for events and other arrangements and are as such only meant for short term temporary assembly and the following disassembly. Dancover warranty applies only to the normal use of the Product, normal wear and tear excepted, in accordance with written use instructions or manual. The warranty does not apply to damage caused by accident, abuse, misuse, or modification of the Product.

Warranty Information

Please visit dancovershop.com for information on warranty.

Please always check our website for the latest safety advice and manual.

Warning

1

The pipes are covered in oil. Before you set up your tent please remove the oil carefully to keep the cover clean.

2

Take note that the tent needs to be handle with care to avoid damages.

3








Do not force the frame as they may be damage in the process.

4

Tents are meant as temporary shelters and must be evacuated under extreme weather conditions.

Please select a suitable site for the tent to avoid damage to underground sprinkler systems, water, gas or electrical lines.


7x12 -2,3 PARTY TENT SEMI PRO, CombiTent

| | | | | | | | | | | | | | | | | | | | |
|---|---------|--|--------|---|--------|--|--------------------|--|--------|---|---------|---|--------|--------|--|--------------|--|--------|--|
| 2188mm  | | 1880mm  | | 1700mm  | | 1715mm  | | 620mm  | | 2210mm  | | 110°  | | | | | | | |
| 1. | 14 PCS | 2. | 42 PCS | 3. | 28 PCS | 4. | 14 PCS | 5. | 7 PCS | 6. | 6PCS | 7. | 4PCS | | | | | | |
| 140°  | | 140°  | | 140°  | | 110°  | | 110°  | |  | |  | | | | | | | |
| 8. | 2PCS | 9-1 | 4PCS | 9-2 | 1 PCS | 10-1 | 2 PCS | 10-2 | 8PCS | 11. | 4PCS | 12. | 10 PCS | | | | | | |
|  | |  | |  | |  | |  | |  | | | | | | | | | |
| 13. | 2PCS | 14. | 2PCS | 15-1 | 2 PCS | 15-2 | 8PCS | 16. | 4PCS | 17. turn buckle set(roof) | | 8PCS | | | | | | | |
|  | |  | |  | |  | |  | | | | | | | | | | | |
| 18. turn buckle set(side) | | 8PCS | | 19.super peg | | 10PCS | | 20.spiral peg | | 4pcs | | 21.middle peg | | 18 pcs | | 22.small peg | | 54 PCS | |
|  | | M6x25  | | M6  | | M8x50mm  | | M8x60mm  | | M8  | | | | | | | | | |
| 24.spencer | 2PCS | 25.screw | 28 PCS | 26.nuts | 28 pcs | 27.50mm screw | 96PCS | 28.60mm screw | 84 pcs | 29.locknuts | 180 pcs | | | | | | | | |
|  | | | |  | |  | |  | |  | |  | | | | | | | |
| 30. long bungeeball | 210 PCS | | | 32.rope | 4PCS | 34.roof | 1 pcs (4 sections) | 35.sidewall | 12PCS | 36.endwall Large door | 1PC | 37.endwall Small door | 1PC | | | | | | |


7x12 -2,3 PARTY TENT SEMI PRO, CombiTent

CombiTent roof explained


7x6




7x8




7x10




7x12




7x14



When you are making your CombiTent **shorter**. Use the velcro overlay to detach roof sections.




Use the velcro overlay to attach 2 roof sections to each other.



7x12 -2,3 PARTY TENT SEMI PRO, CombiTent


Select a flat ground for the tent, unpack the carton and check that all the parts including tubes, tent and accessories... etc. are present same as on the part list.
Assemble the framework of rooftop by joining the parts (7, 8, 9-1,9-2, 10-1, 10-2, 11, 12) together with poles (2.3).To ensure the screw fixed to every pole tightly



7x12 -2,3 PARTY TENT SEMI PRO, CombiTent

II


Attach one end of supported pole (4.5) to the joints(8,11), Strengthen the frame by using screws and turnbuckle set (17). Long screws are used on all connection between 50mm and 54mm pipe. Short screws are used on connection between 42mm and 38mm pipes.



7x12 -2,3 PARTY TENT SEMI PRO, CombiTent


III

Cover the roof on the frame and attach it with the bungee balls. Take care of the tension of the bungee balls, if you use too many on one side of the tent, it may be too tight to tie the other side. Leg 1 with holes, should be on both sides of the tent.



IV

Attach all supported poles (1) to the joints (7.10), built-up the framework use the super pegs to fix the poles into the ground. Tighten the frame with the turnbuckle set (18).



7x12 - 2,3 PARTY TENT SEMI PRO, CombiTent

V

Attach the sidewalls to the frame using the bungees.


Attach the endwall directly to the roof with velcro.

Connect the leg covers to the sidewalls and endwalls with velcro as shown.

Use the short ground pegs to fasten the endwalls to the ground.

The guy rope runs from every corner of the tent and is braced to the ground using the spiral pegs.

The super pegs provide the tent with additional tension and stability



DANCOVER[®]



Contact information

Head office:

Dancover A/S
Lyngevej 16A, Nørre Herlev 3400 Hillerød Denmark

For more information please visit:
www.dancovershop.com

National contact

Denmark:

denmark@dancover.com

Sweden:

[sverige@dancover.com](mailto: sverige@dancover.com)

Spain:

espana@dancover.com

Norway:

norge@dancover.com

UK:

uk@dancover.com

Finland:

suomi@dancover.com

Italy:

italia@dancover.com

Nederland:

nederland@dancover.com

Germany:

germany@dancover.com

Poland:

polska@dancover.com

Switzerland:

schweiz@dancover.com

Ireland:

ireland@dancover.com

France:

france@dancover.com

Portugal:

portugal@dancover.com

Austria:

austria@dancover.com

Belgium:

belgique@dancover.com

Luxembourg:

luxembourg@dancover.com